

ifm electronic




Operating instructions
AS-i universal module

ecomat300[®]

AC2035

UK

80235671/00 02/2016



Contents

1 Preliminary note.....	3
2 Safety instructions	3
3 Functions and features	3
4 Installation.....	4
5 Operating and display elements	4
6 Addressing.....	4
7 Electrical connection.....	4
7.1 Terminal connection and assignment of the data bits.....	5
8 Operation.....	6
9 Maintenance, repair and disposal.....	6
10 Technical data.....	6

1 Preliminary note

- ▶ Instructions
- > Reaction, result



Important note

Non-compliance may result in malfunction or interference.

2 Safety instructions

- Please read the operating instructions prior to set-up of the device. Ensure that the product is suitable for your application without any restrictions. UK
- The unit complies with the relevant regulations and EC directives.
- Improper or non-intended use may lead to malfunctions of the unit or to unwanted effects in your application.
- Installation, electrical connection, set-up, operation and maintenance of the unit must be carried out by qualified personnel authorised by the machine operator.

3 Functions and features

The AS-i module operates as a slave with bidirectional data transfer in the AS-i network (AS-i profile: S7.F.F). It connects 4 sensors (2-wire sensors or pnp 3-wire sensors) and 4 actuators (pnp) with the AS-i master.

- Maximum number of modules per master: 31
- Current supply from the AS-i system, a total of 200 mA per module
- Output current: 2 A per channel, 4 A per module at 24 V DC \pm 15 %
- Watchdog: If the connection to the master is interrupted, the 4 outputs are switched off.
- Sensor/actuator connection via PG7 cable glands and cage clamps
- AS-i and external power connection via the FC-E module lower part


4 Installation



▶ Disconnect power before installation.

▶ Mount the module on a wired lower part of the AS-i network, tightening torque 0.8 Nm.

5 Operating and display elements



1: LEDs yellow / red / green

2: Label

3: PG7 cable gland

6 Addressing

▶ Plug the module into the addressing unit. Assign a free address between 1 and 31, on delivery the address is 0.

7 Electrical connection



The unit must be connected by a qualified electrician.

The national and international regulations for the installation of electrical equipment must be adhered to.

▶ Disconnect power.

▶ Connect the unit.

- Pass the connection cables through the cable glands and connect the wires to the cage clamps.



The external voltage must have a safe separation to PELV. Do not connect the inputs with external potential.


7.1 Terminal connection and assignment of the data bits

Terminal connection	Input 1			Input 2			Input 3			Input 4		
	+	IN	-	+	IN	-	+	IN	-	+	IN	-
Data bit	D0			D1			D2			D3		
Input	I+	I1	I-	I+	I2	I-	I+	I3	I-	I+	I4	I-
Terminal connection	Output 1			Output 2			Output 3			Output 4		
	nb	Out	-	nb	Out	-	nb	Out	-	nb	Out	-
Data bit	D0			D1			D2			D3		
Output	nb	O1+	O1-	nb	O2+	O2-	nb	O3+	O3-	nb	O4+	O4-

UK

nb = not used

- Connect the actuators with the outputs O1...O4.



nb = not used

Parameter bits P0

Watchdog for all outputs activated* / deactivated (* default), P1...P3 are not used.

8 Operation

Check whether the unit operates correctly. Display by LEDs:

- LED AUX green lights: external voltage ok
- LEDs yellow light: inputs/outputs switched
- LED PWR/FAULT red lights: AS-i communication error, slave does not participate in the "normal" exchange of data, e.g. slave address 0
- LED PWR/FAULT green lights: voltage supply via the AS-i network ok
- LED PWR/FAULT alternately flashes green/red: peripheral fault, e.g. sensor supply overloaded or shorted

9 Maintenance, repair and disposal

The operation of the unit is maintenance-free.

After use dispose of the unit in an environmentally friendly way in accordance with the applicable national regulations.

10 Technical data

Technical data and further information at www.ifm.com