



Operating instructions
AS-i CompactLine module

UK


AC2464

AC2465

AC2467

AC2468

80231909/00 03/2019



Contents

1 Preliminary note.....	3
2 Safety instructions	3
3 Functions and features	3
4 Installation.....	4
5 Electrical connection.....	6
5.1 External protective circuitry for inductive loads	6
6 Addressing.....	6
7 Pin connection / data bits.....	6
8 Operating and display elements	10
9 Maintenance, repair and disposal.....	11
10 Technical data.....	11
11 Scale drawing	11

1 Preliminary note

► Instruction

> Reaction, result



Important note

Non-compliance can result in malfunction or interference.



Information

Supplementary note.

2 Safety instructions

UK

- Please read the operating instructions prior to set-up of the device. Ensure that the product is suitable for your application without any restrictions.
- The unit conforms to the relevant regulations and EC directives.
- Improper or non-intended use may lead to malfunctions of the unit or to unwanted effects in your application.
- Installation, electrical connection, set-up, operation and maintenance of the unit must only be carried out by qualified personnel authorised by the machine operator.

3 Functions and features

AC2464 / AC2465

- maximum number of modules per master: 31
- AS-interface version 2.1

AC2467 / AC2468

- maximum number of modules per master: 62
- AS-interface version 3.0

4 Installation



▶ Disconnect the system from power before installation.



▶ For installation choose a flat mounting surface.
The entire bottom of the module must lie flat on the mounting surface.

- ▶ Fix the module onto the mounting surface using M4 screws and washers (1).
Tightening torque 1.8 Nm.
Use stainless steel sleeve (E70402)* for installation in case of high mechanical stress.
- ▶ Connect the plugs of the sensors (2) to the M12 sockets.
Tightening torque 0.8...1.5 Nm.
- ▶ Cover the unused sockets with protective caps (E73004)*.
Tightening torque 0.6...0.8 Nm.
- ▶ The flat cable end seal (E70413)* must be used if the module is at the end of the cable line.


*to be ordered separately



In case of interference coupling to the sensor cables or the black flat cable (24 V DC auxiliary supply) the use of the functional earth springs can improve the EMC.

Requirement: An interference-free and low-resistance connection to the machine ground.

- ▶ If necessary, you can ground the module via the functional earth springs (3).



- 1: M4 screws and washers (not supplied with the device). Tightening torque 1.8 Nm.
- 2: M12 connector. Tightening torque 0.8...1.5 Nm.
- 3: functional earth springs



Observe the maximum tightening torque of the connection cable.

5 Electrical connection



The unit must be connected by a qualified electrician.

The national and international regulations for the installation of electrical equipment must be adhered to.



Intended for connection to class 2 (cULus class 2) circuits only.

▶ Disconnect power.

▶ Connect the unit.

5.1 External protective circuitry for inductive loads

The switch-on and switch-off capacity for triggering solenoids is rated up to 20 W (IEC 60947-5-1, utilisation category DC-13).



Recommendation: For inductive loads use a free wheel diode on the load. Ifm electronic offers valve plugs with integrated free wheel diodes.

6 Addressing

AC2464 / AC2465

▶ Assign a free address between 1 and 31.

The address is set to 0 at the factory.

AC2467 / AC2468

▶ Assign a free address between 1A and 31B.

The address is set to 0 at the factory.

7 Pin connection / data bits

inputs

1: sensor supply +

2+4: data input

3: sensor supply -

5: functional earth



outputs

3: external voltage AUX -

4: switching output

5: functional earth (FE)

1,2: not connected (n.c.)



connector M12 AC2464 / AC2468

1: AS-i +
3: AS-i -

**connector M12 AC2465 / AC2467**

1: AS-i +
2: AUX -
3: AS-i -
4: AUX +

**AC2464**

4 inputs

AS-i profile S-0.0.E / extended addressing mode: no

Data bit	D0	D1	D2	D3
Input	1	2	3	4
Socket	I-1	I-2	I-3	I-4
Pin	2+4	2+4	2+4	2+4

AC2465

4 inputs / 4 outputs

AS-i profile S-7.0.E / extended addressing mode: no

Data bit	D0	D1	D2	D3
Input	1	2	3	4
Socket	I-1	I-2	I-3	I-4
Pin	2+4	2+4	2+4	2+4
Output	1	2	3	4
Socket	O-1	O-2	O-3	O-4
Pin	4	4	4	4

UK

AC2467

4 inputs / 4 outputs

AS-i profile S-7.A.7 / extended addressing mode: yes

Data bit	D0	D1	D2	D3	
Input	I1	I2	I-3	I-4	
Socket	I-1/2	I-1/2	I-2	I-3/4	I-4
Pin	4	2	4	2	4
Output	O1	O2	O3	O4	
Socket	O-1	O-2	O-3	O-4	
Pin	4	4	4	4	


Inputs Y-circuit	Outputs
Inputs 1: sensor supply + 2: data input 3: sensor supply + 4: data input 5: functional earth (FE)	Outputs 3: external voltage AUX - 4: switching output 5: functional earth (FE) 1.2: not connected (n.c.)

AC2468

4 inputs / AS-i profile S-0.A.E / extended addressing mode: yes

Data bit	D0	D1	D2	D3		
Input	I1	I2	I3	I4		
Socket	I-1/2	I-1/2	I-2	I-3/4	I-4	
Pin	4	2	4	4	2	4

Inputs Y-circuit




Inputs


- 1: sensor supply +
- 2: data input
- 3: sensor supply +
- 4: data input
- 5: functional earth (FE)

UK

8 Operating and display elements



- 1: LED AS-i
- 2: LED FAULT
- 3: LED IN/OUT



- 1: LED AS-i
- 2: LED AUX
- 3: LED IN/OUT
- 4: LED FAULT

LED AS-i green lights:

LED AUX green lights:

LED IN/OUT lights:

AS-i voltage supply ok

AUX voltage supply ok (AC2465 / AC2467)

input / output switched

LED FAULT red lights:

AS-i communication error, slave does not participate in the "normal" exchange of data, e.g. slave address 0

LED FAULT red flashes:

peripheral fault, e.g. sensor supply / output overloaded or shorted, communication active



Overload and short circuit of the input supply and the outputs are signalled as peripheral fault to the AS-i master (version 2.1 or higher).

9 Maintenance, repair and disposal

UK

The operation of the unit is maintenance-free.

After use dispose of the unit in an environmentally friendly way in accordance with the applicable national regulations.

10 Technical data

Technical data and further information at www.ifm.com.

11 Scale drawing

AC2464 / AC2468

