




Operating instructions  
ProcessLine analogue module

**AC2916**

**GB**

11461365/00 05/2022



# Contents

1 Safety instructions .....	3
2 Functions and features .....	4
3 Operating and display elements .....	4
4 Electrical connection.....	5
4.1 Wiring .....	5
4.1.1 AS-i input .....	5
4.1.2 Analogue input.....	6
4.2 Current measurement.....	6
5 Addressing.....	6
5.1 Addressing with the addressing unit AC1154 .....	6
5.2 Parameter setting of the analogue module.....	7
5.3 Measuring range of the unit.....	8
6 Operation.....	8
7 Scale drawing.....	9

## Preliminary note

- Operating elements are indicated as follows:  
Example: [Out off] = button "Out off"
- An instruction is indicated by "►":  
Example: ► Disconnect power.
- A reaction to the action is indicated by ">":  
Example: > yellow LED lights.

## 1 Safety instructions

- Please read the product description prior to set-up of the unit. Ensure that the product is suitable for your application without any restrictions.
- The unit conforms to the relevant regulations and EC directives.
- Improper or non-intended use may lead to malfunctions of the unit or to unwanted effects in your application.

That is why installation, electrical connection, set-up, operation and maintenance of the unit must only be carried out by qualified personnel authorised by the machine operator.

## 2 Functions and features


The slave converts analogue input signals and transfers them to the AS-i master via the AS-Interface. The AS-i module operates as a slave with bidirectional data transfer in the AS-i network.

The data transfer to the host is asynchronous according to the AS-i profile S-7.3.E and the AS-i specification 3.0, downward compatible.

- maximum number of modules per master: 31
- current measurement 4...20 mA
- time for converting the measured values in the slave
  - for one channel: 60 ms
  - for two channels: 120 ms
  - for three channels:
    - channel 1: 120 ms
    - channels 2 and 3: 240 ms
  - for four channels: 240 ms

When the sensors are supplied from AS-i the load must not exceed 380 mA, the load for an individual sensor connection must not exceed 200 mA. There is an electrical connection between the sensor and AS-i.

## 3 Operating and display elements



## 4 Electrical connection

- ▶ Do not remove the mounted protective caps (E70297) before the sensor plugs are connected to the M12 sockets.

To guarantee the protection rating IP 69K

- unused sockets must be covered with these protective caps (tightening torque 0.6...0.8 Nm).
- the M12 connectors must be tightened with a tightening torque of 0.6...0.8 Nm.



The round cable connected to AS-i should not be longer than 2 m.



The signal cable length for external devices (sensors, actuators) is to be limited to max. 10 m.

The signal cables must not leave the building.

The device shall be supplied from an isolating transformer having a secondary Listed fuse rated as noted in the following table.

Overcurrent protection		
Control-circuit wire size		Maximum protective device rating Ampere
AWG	(mm <sup>2</sup> )	
26	(0.13)	1
24	(0.20)	2
22	(0.32)	3
20	(0.52)	5
18	(0.82)	7
16	(1.3)	10

### 4.1 Wiring

#### 4.1.1 AS-i input

- 1: AS-i +
- 2: n.c.
- 3: AS-i -
- 4: n.c.
- 5: FE (functional earth)



## 4.1.2 Analogue input

- 1: 24 V (sensor supply)
- 2: AI + (input current loop)
- 3: 0 V / AI - (sensor supply / output current loop)
- 4: n.c.
- 5: FE (functional earth)




## 4.2 Current measurement

In all the following wiring diagrams the indicated pin connection refers to the unit.


Connection of a 2-wire sensor without own supply

- 1: sensor supply +24 V
- 2: AI+ analogue input
- 3: sensor supply 0 V / analogue input AI-
- 5: functional earth




Wiring of a 2-wire sensor with electrically isolated and earth-free supply

- 1: sensor supply +24 V
- 2: analogue input AI+
- 3: sensor supply +0 V / analogue input AI-
- 5: functional earth



Connection of a 3-wire sensor without own supply

- 1: sensor supply +24 V
- 2: analogue input AI+
- 3: sensor supply +0 V / analogue input AI-
- 5: functional earth



## 5 Addressing

The address is set to 0 at the factory.

### 5.1 Addressing with the addressing unit AC1154

- Addressing the unit via the AS-i connection.



Connected sensors might exceed the ability of the addressing unit to supply power.

- Remove the sensors from the unit and address them.

## 5.2 Parameter setting of the analogue module

Parameter bit	Description		Remarks			
P0	1	50 Hz	50/60 Hz suppression			
	0	60 Hz				
P1, P2	Channel activation					
	P1	P2	Channel 1	Channel 2	Channel 3	Channel 4
	0	0	on	off	off	off
	0	1	on	on	off	off
	1	0	on	on	on	off
1	1	on	on	on	on	
P3	peripheral fault if outside the measuring range			1	peripheral fault indication active	
				0	peripheral fault indication non active	

## 5.3 Measuring range of the unit

► For the measuring ranges and their significance please refer to the following tables:

Range [mA]	Units dec.	Units hex.	LED	Peripheral fault	Description
< 3.4	32768 → 32767 *	8000 → 7FFF *	flashes	on***	wire break
3.4...3.59	3400...3599 → 32767 *	0D48...0E0F → 7FFF *	flashes	off	below nominal range
3.6...22	3600...22000	0E10...55F0	on	off	extended and nominal range**
22.01...23	22001...23000 → 32767 *	55F1...59D8 → 7FFF *	flashes	off	above nominal range
> 23	32767	7FFF	flashes	on***	outside range

Note:


\* the master replaces the value transmitted by the slave with the default value 7FFFh (32767)

\*\* the accuracy is only guaranteed in the nominal range (4...20 mA) but not in the extended nominal range.

\*\*\* only for the parameter bit 3 = 1

## 6 Operation

Check whether the unit operates correctly. Display by LEDs.






• LED AI1...AI4 yellow off	sensor input is disabled (see parameter bit P1 and P2)
• LED AI1...AI4 yellow on	analogue signal in the measuring range
• LED AI1...AI4 yellow flashes	analogue signal outside the measuring range or no sensor connected
• LED green PWR on	AS-i voltage is applied
• LED red FAULT on	AS-i communication error
• LED red FAULT flashes	peripheral fault*

\* peripheral fault

A peripheral fault is displayed:

- if at least one of the analogue signals is outside the value range (P3)
- if nothing is connected to at least one analogue channel although the respective channel (P3) is activated
- in case of overload or short circuit of the sensor supply

## 7 Scale drawing



Technical data and further information at  
[www.ifm.com](http://www.ifm.com)