

Diffuse mode sensor OBD1100-R100-2EP-IO-V45-IR-Y



- Miniature design with versatile mounting options
- Extended temperature range -40 °C ... 60 °C
- High degree of protection IP69K
- IO-Link interface for service and process data
- Infrared light design












Function


The miniature optical sensors are the first devices of their kind to offer an end-to- end solution in a small single standard design — from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.

Dimensions





Technical Data

General specifications 2 ... 1100 mm Detection range Detection range min. 10 ... 60 mm Adjustment range 60 ... 1100 mm Reference target standard white, 100 mm x 100 mm LED Light source Light type modulated infrared light 850 nm LED risk group labelling exempt group Diameter of the light spot approx. 100 mm at a distance of 1000 mm 5.4° Opening angle Ambient light limit EN 60947-5-2 Functional safety related parameters 724 a $MTTF_d$ Mission Time (T_M) 20 a Diagnostic Coverage (DC) 0 % Indicators/operating means LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode Operation indicator Function indicator constantly on - object detected constantly off - object not detected Control elements Light-on/dark-on changeover switch Control elements Sensing range adjuster **Electrical specifications** 10 ... 30 V DC Operating voltage U_{B} max. 10 % Ripple No-load supply current I_0 < 25 mA at 24 V supply voltage Protection class Ш Interface Interface type IO-Link (via C/Q = BK) IO-Link revision 1.1 Device ID 0x1101A0 (1114528) Transfer rate COM2 (38.4 kBit/s) Min. cycle time 2.3 ms Process data input 1 Bit Process data output 2 Bit Process data width SIO mode support ves Compatible master port type Output Switching type The switching type of the sensor is adjustable. The default setting is: C/Q - BK: NPN normally open / light-on, PNP normally closed / dark-on, IO-Link /Q - WH: NPN normally closed / dark-on, PNP normally open / light-on Signal output 2 push-pull (4 in 1) outputs, short-circuit protected, reverse polarity protected, overvoltage protected Switching voltage max. 30 V DC max. 100 mA, resistive load Switching current Usage category DC-12 and DC-13 Voltage drop $U_{\text{d}} \\$ ≤ 1.5 V DC

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Conformity

Switching frequency Response time

Product standard

Communication interface

Approvals and certificates

1000 Hz


IFC 61131-9

EN 60947-5-2


0.5 ms

Technical Data			
UL approval	E87056, cULus Listed, class 2 power supply, type rating 1		
Ambient conditions			
Ambient temperature	-40 60 °C (-40 140 °F) , fixed cable -25 60 °C (-13 140 °F) , movable cable not appropriate for conveyor chains		
Storage temperature	-40 70 °C (-40 158 °F)		
Mechanical specifications			
Housing width	11 mm		
Housing height	37.1 mm		
Housing depth	21.5 mm		
Degree of protection	IP67 / IP69 / IP69K		
Connection	2 m fixed cable + RJ45		
Material			
Housing	PC (Polycarbonate)		
Optical face	PMMA		
Mass	approx. 10 g		
Cable length	2 m		

Connection Assignment





Assembly




- 1 Light-on/Dark-on changeover switch
- 2 Sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

Characteristic Curve








Accessories

	OMH-ML100-09	Mounting aid for round steel ø 12 mm or sheet 1.5 mm 3 mm
4	OMH-R10X-01	Mounting bracket
	OMH-R10X-02	Mounting bracket

Accessories		
	OMH-R10X-04	Mounting bracket
i ii	OMH-R10X-10	Mounting bracket
	OMH-ML100-03	Mounting aid for round steel ø 12 mm or sheet 1.5 mm 3 mm
	OMH-ML100-031	Mounting aid for round steel ø 10 14 mm or sheet 1 mm 5 mm
110	ICE2-8IOL-G65L-V1D	EtherNet/IP IO-Link master with 8 inputs/outputs
II.	ICE3-8IOL-G65L-V1D	PROFINET IO IO-Link master with 8 inputs/outputs
	ICE1-8IOL-G30L-V1D	Ethernet IO-Link module with 8 inputs/outputs
6:56 6:16 6:16 6:16 7:19 8:19	ICE1-8IOL-G60L-V1D	Ethernet IO-Link module with 8 inputs/outputs
	ICE2-8IOL-K45P-RJ45	EtherNet/IP IO-Link master with 8 inputs/outputs, DIN rail, push-in connectors
8	ICE2-8IOL-K45S-RJ45	EtherNet/IP IO-Link master with 8 inputs/outputs, DIN rail, screw terminal
	ICE3-8IOL-K45P-RJ45	PROFINET IO IO-Link master with 8 inputs/outputs, DIN rail, push-in terminals
8	ICE3-8IOL-K45S-RJ45	PROFINET IO IO-Link master with 8 inputs/outputs, DIN rail, screw terminal
SHO	IO-Link-Master02-USB	IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection





- 1 Light-on / dark-on changeover switch
- 2 Sensing range / sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range /sensitivity adjuster for more than 180 degrees.

Sensing Range / Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range /sensitivity adjuster for more than 180 degrees.