**Dimensions** 



### **Model Number**

### ML7-55/25/102/115


Retroreflective sensor with 2 m fixed cable

### **Features**

- Reliable sensor for standard • applications
- Miniature design with versatile ٠ mounting options
- Automatic adjustment of sensitivity • via TEACH-IN
- Resistant against noise: reliable ٠ operation under all conditions
- Clear and functional display concept ٠ for the operating modes
- · Certified by ECOLAB


### **Product information**

Small, robust, effective, and reliable - these are the properties of the ML7 sensor series. Due to their small size, number of versions, and two different lens positions, they are particularly suited for installation in tight spaces. The robust design and high quality of Pepperl+Fuchs mean they can also be used under harsh environmental conditions. The efficient technology, switching frequencies up to 1000 Hz, high resistance to ambient light, and 4-in-1 output make the series suitable for non-contact object detection.






### **Electrical connection**



= Dark on

### Indicators/operating means



1	Operating display	green
2	Signal display	yellow
3	TEACH-IN button	
4	Emitter	
5	Receiver	

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

<sup>5</sup> PEPPERL+FUCHS 1

#### **Technical data** General specifications Effective detection range 0...3m 0.03 ... 3 m Reflector distance 3.5 m Threshold detection range H85-2 reflector Reference target Light source I FD Light type modulated visible red light , 635 nm Polarization filter yes Diameter of the light spot approx. 180 mm at a distance of 3.5 m Angle of divergence approx. 3 Ambient light limit 40000 Lux Functional safety related parameters 1530 a Mission Time (T<sub>M</sub>) 20 a Diagnostic Coverage (DC) 0% Indicators/operating means Operation indicator LED green, flashes in case of short-circuit Function indicator LED yellow, lights up when light beam is free, flashes when falling short of the stability control Control elements Teach-In key **Electrical specifications** 10 ... 30 V DC , class 2 Operating voltage UB max. 10 % No-load supply current < 20 mA $I_0$ Switching type light on Signal output 1 NPN output, short-circuit protected, reverse polarity protected, open collector max. 30 V DC Switching voltage max. 100 mA Switching current Voltage drop Ud $\leq$ 1.5 V DC 1000 Hz Switching frequency 0.5 ms Response time Conformity Product standard EN 60947-5-2 Ambient conditions -20 ... 60 °C (-4 ... 140 °F) Ambient temperature -40 ... 75 °C (-40 ... 167 °F) Storage temperature Mechanical specifications Housing width 23 mm Housing height 31 mm Housing depth 11 mm Degree of protection IP67 / IP69K Connection 2 m fixed cable Material Housing PC (glass-fiber-reinforced Makrolon) Optical face PMMA approx. 50 g

#### Approvals and certificates

Protection class UL approval

Mass

MTTF<sub>d</sub>

Ripple

Output

CCC approval

II, rated voltage  $\leq$  250 V AC with pollution degree 1-2 according to IEC 60664-1 cULus CCC approval / marking not required for products rated ≤36 V

### Accessories

Montagekit OMH-ML7-01 Mounting set consisting of bracket OMH-ML-01 sheet OMH-ML7-03, and fastening material

Montagekit OMH-ML7-02 Mounting set consisting of bracket OMH-ML-02 sheet OMH-ML7-03, and fastening material

### OMH-ML7-01

Mounting aid for ML7 and ML8 series, Mounting bracket

**OMH-ML7-02** Mounting aid for ML7 and ML8 series, Mounting bracket

# OMH-ML7-03


Mounting aid for ML7 and ML8 series, Fixing plate


Suitable reflectors and cable sockets can be found in the Internet

www.pepperl-fuchs.com

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com

## **Curves/Diagrams**





### **Teach-In**

Connect the sensor to operating voltage, the LED green lights up constantly. The sensor operates at max. sensitivity (delivery status) or with the last teached values.

Mount suitable reflector opposite light beam switch.

- Adjust the unit to the reflector.
- Press the Teach-In button as an acknowledgement the green LED will quickly turn off one time.
- Press the Teach-In button until both LEDs green and yellow are blinking in parallel (2Hz). Release the Teach-In button now.
- While the green and yellow LEDs are blinking alternating (2 Hz) the unit is in the internal set up procedure.
- Teach-In successful: Both LEDs green and yellow are on. The unit is ready to use and in switching mode now.
- Teach-In not successful: Both LEDs are flashing alternating (4 Hz) for approx. 5 seconds. Afterwards the sensor returns to max. sensitivity setting. Please retry the Teach-In procedure beginning by step 1.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Germany: +49 621 776 1111 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com